

HOW TO ASSEMBLE YOUR PLANT CLONING MACHINE

- Except for the water pump and sprayer manifold, rinse all parts in lukewarm water.
- The orientation of the red sprayers is factory set for better spraying coverage (*Figure A*). If you feel that customization of the spray pattern is required; simply rotate the red sprayers as required.
- Carefully fit the water pump onto spray manifold.
 To prevent breaking the manifold tube, avoid using excessive force.
- Use the pump suction cups to adhere the pump to the base of the tub.

- There is a mark in the centre of the tub base; place the pump into position as shown in *Figure B* (note the position of the power cord). Feed the power cord through the slot in the rim on the short side of the tub.
- For a correct fit, place the lid on the base as per *Figure C*, ensuring that it is watertight.
- Before putting clones into the system, fill with water to a level just under the red sprayers in the tub, then place the lid back on. Turn on the machine to rinse all internal parts. Run for at least 5 minutes, then discard and replace the water.

 Repeat this procedure.







