









# **ASSEMBLY INSTRUCTIONS**

### STEP 1

Construct the metal tent frame by assembling the metal poles, corners, and connectors as per diagram. To avoid damage, it is very important to check that all the poles are pushed completely into each corner/connector/joiner. Use a rubber mallet to gently tap fittings into the poles if necessary. Failure to do so will not only make the tent cover difficult to fit but may also stretch the seams and allow emissions of light from the functioning tent.

#### STEP 2

Un-zip the zipper systems all the way.

### STEP 3

Locate the tents' roof (*Refer PIC A*) and place neatly and carefully over all 4 corners of the top frame ensuring a snug fit. To avoid damage, it is important that you hang the shallow and deep bars before doing the next step.

#### STEP 4

Slip the base section of the tent cover beneath assembled "A" and "D" poles, and ensure it fits in a neat and precise manner around the tent frame corners and sides (*Refer PIC B*).

### STEP 5

Close up the zipper system carefully. You may have to push the upright poles in as you zip up around each corner (Refer PIC C).

### STEP 6

Attach waterproof floor tray in place and Nylon fabric straps. Zip up the zipper on the front *(Refer PIC D)*.

## DISMANTLING OF SMART TENT

- 1 Ensure the tent is clean and dry before dismantling.
- Reverse the operation as per above instruction.

  (Step 6> Step 5> Step 4> Step 3> Step 2> Step 1)

  To ensure your Smart Tent maintains the same "lightproof" quality, always dismantle carefully and avoid stretching the seams of the tent cover.











seaHawk is distributed in Australia by Holland Forge PTY LTD.

