




GROW TENT

2M HIGH 2.9 x 1.45M

8438

INSTRUCTION MANUAL



WHAT'S IN THE BOX

Please take the time, before assembling tent, to make sure all contents are present within this box.

8



4



6



1



14



A 136.5cm

6



B 97.5cm

6



C 97.5cm

2



Shallow


E 145.5cm

4




Deep

F 145.5cm




FRONT




RHS




REAR



LHS



ROOF



SeaHawk TENT KEY

	ZIPPER DOOR/ ACCESS		OUTLET VENT 275
	WINDOW		INTAKE PORT 275
	AIR INTAKE		COOL TUBE PORT 175
	DRAIN OUTLET 130 X 50MM		CABLE PORT 100

ASSEMBLY INSTRUCTIONS

STEP 1

Construct the metal tent frame by assembling the metal poles, corners, and connectors as per diagram. **To avoid damage, it is very important to check that all the poles are pushed completely into each corner/connector/joiner. Use a rubber mallet to gently tap fittings into the poles if necessary.**

Failure to do so will not only make the tent cover difficult to fit but may also stretch the seams and allow emissions of light from the functioning tent.

STEP 2

Un-zip top and base zipper system from the FRONT SIDE (where it has **seaHawk** logo and see-through windows) all the way to the back side of the tent. **It is important you leave the zippers on BACK SIDE closed.**

STEP 3

Locate the tents' ROOF (**Refer PIC A**) and place neatly and carefully over all 4 corners of the top frame, ensuring a snug fit.

STEP 4

Slip the base section of the tent cover beneath the assembled frame. Ensure it fits in a neat and precise manner around the tent frame corners and sides (**Refer PIC B**).

STEP 5

Carefully close the two large horizontal zipper systems simultaneously. You may have to push the upright poles in a bit as you zip around each corner (**Refer PIC C**).

STEP 6

Attach shallow/deep bars, waterproof floor trays, and pouch in place along with the Nylon fabric straps.

DISMANTLING OF SMART TENT

1 Ensure the tent is clean and dry before dismantling.

2 Reverse the operation as per above instruction. (Step 6> Step 5> Step 4> Step 3> Step 2> Step 1)
To ensure your **Smart Tent** maintains the same "lightproof" quality, always dismantle carefully and avoid stretching the seams of the tent cover.



PIC A



PIC B



PIC C



PIC D



seaHawk is distributed in Australia by Holland Forge PTY LTD.

