


MODEL PART DIAGRAM



BACK



WHERE TO USE



Allow 30 - 45 cm of space between TVs, radios, and other electronic products

electromagnetic interference from certain electronics may cause product malfunction

Place indoors away from direct sun light


direct exposure may cause product malfunction or failure.

Only place on hard, flat surfaces

flimsy or slanted surfaces may result in abnormal noise and vihrations

1

CONTROLS



01. Smart Sensor

Automatically detects indoor air quality.

02. Check Filter Indicator

LED light indicates when it is time to change the filter.

03. Reset Button

After replacing a filter, press the RESET button for at least 5 seconds

04. PlasmaWave® Indicator

Indicates whether PlasmaWave® is enabled or disabled.

05. Timer Indicator

If timer has been set, the LED light Indicates the set time of operation

06. Child Lock Indicator

LED light indicates whether Child Lock mode is enabled or disabled

07. Light Sensor

Detects the amount of ambient light within the environment, to adjust the brightness of the LED indicators.

08. Power Button

Turns the unit on or off.

09. Mode / Fan Speed Button

Every time the Mode button is pressed, the Mode LED light will cycle through the settings. (Auto, Sleep, Low, Medium, High, Turbo)

10. PlasmaWave® Button

Enables or disables PlasmaWave®.

11. Timer / Air Quality Button

Press to cycle through and set desired length of operation (1hr, 4hr, 8hr, [NO TIMER]). Press and hold for 3 seconds to enable or disable the Air Quality light.

12. Child Lock Button

Press and hold for 3 seconds to enable or disable the Child Lock mode.

INITIAL OPERATION



- Insert the unit plug into an electrical outlet.
- · The Control Panel lights will turn on and off.



2 Press the 'Power' button



• During the first 4 minutes of power up, the Air Quality light will flash as the Smart Sensors measure the air quality in the environment, after which normal operation will begin.

Auto

PLASMAWAVE®

- 3 By default, when the unit first powers on, the mode will be set to Auto with PlasmaWave® enabled
- When in Auto Mode the fan speed will be automatically adjusted according to the environments air quality.
- PlasmaWave® works to remove harmful airhorne contaminants



• NOTICE

- · In Auto mode, as the indoor air quality improves, the fan speed will automatically be reduced to Low
- When the unit is running, you may hear a chirping or buzzing sound. The sound is from large particles passing through PlasmaWave®, it is normal and does not signify product failure. To disable PlasmaWave®, see page 2.

3

INSTALLING FILTERS

This product comes with all of the required filters. The protective plastic wrap must be removed from the filters before use.

- X Operating the unit without removing the plastic wrap may result in product failure.
- X Unplug and make sure the unit is turned off before installing filters. * The unit will automatically power off when front panel is opened.




- 1 Remove the front panel by grasping its upper edge and gently pulling towards yourself.
 - · To remove the front panel, the latch at the lower edge of the panel must be released from



2 Remove the filters from the unit, they are protected inside a plastic wrap.



- 3 Remove filters from protective plastic wrap. · Operating the unit without removing filters
 - from plastic may cause abnormal noise. deformation, or fire as a result of overheating.



- 4 Install the filters until they fit securely in place. Filters must be installed in this order.
- 03. True HEPA Filter (rear) 02. Deodorization Filter (middle)
- 01. Pre-Filter (front)
- · To install the Pre-Filter, insert bottom tabs into the slots on either side of the lower part of the unit, then rotate upward to insert the upper tabs into the slots at the top part of the unit until sides audibly click into place.



Replace the front panel by first inserting the latch at the bottom edge into the base of the unit, then rotate the panel upward toward the top of the unit until it magnetically snaps closed.

FILTER CARE

Changing Filters

When the Check Filter indicator LED is on, it is time to replace both the True HEPA and Deodorization Filter

Filter	Indicator Light	When to service	When to replace
Pre-Filter	none	Clean once every 14 days	Permanent
Deodorization Filter	€]		
True HEPA Filter	Check Filter	Can NOT be WASHED	Lasts up to 12 months

* Intervals between filter replacement may vary depending on environment.

X For optimal use, Pre-Filter can be cleaned once every 14 days which can extend the life of other filters.

※ Pet filter replacement guide separately mentioned on the Pet filter package board.

To purchase replacement Winix filters:

contact our authorized distributor 'Ausclimate' or visit the below web site


- TFI : 1800 122 100
- · www.ausclimate.com.au
- · www.winixaustralia.com.au

Cleaning the filter

Intervals between filter cleaning may vary depending on the air quality.

- 1 Use a vacuum cleaner or soft brush to clean the Pre-Filter. If it is excessively soiled, rinse in room temperature water.
- alcohol or acetone.

Please contact your local dealer





- Do not use benzene, alcohol, or other volatile fluids, which may cause damage or discoloration.
- The Pre-filter is reusable after cleaning, ensuring it has completely dried.
- · Do not use hot water over 40°C or volatile fluids such as paint thinner
- · After washing the pre-filter, allow it to dry completely in a wellventilated area. Otherwise, it may develop a bad odor.

CLEANING THE DUST SENSOR

Cleaning the Dust Sensor

For optimal performance of the Particle Sensor, which detects airborne dust and ultrafine particles, clean it every two months. Clean it more frequently when the unit is running in a place with high dust levels.

1 Open the Dust Sensor



- 2 Use a damp cotton swab to wipe the lens and intake area of the Dust Sensor.
 - To clean the sensor area, use only water. Do not use volatile substances such as alcohol or acetone.
- 3 Wine away any remaining moisture with a dry cottor swab.



- 4 Close the Dust Sensor
 - · The Dust Sensor cover may be cleaned using a vacuum cleaner.



CLEANING CARE

Cleaning the Exterior & Interior

Wipe with a soft damp cloth using room temperature water. Afterwards, wipe it down with a clean dry cloth.

Cleaning the exterior

 For optimal performance, clean the front panel 1-2 times a month.



Cleaning the interior

Open the front panel and clean the interior with a vacuum cleaner.

· For optimal performance, clean the interior 1-2 times a month.



NOTICE

- · When cleaning the unit, always unplug the power cord first and then wait until the unit has cooled off.
- · Never disassemble, repair or modify this unit yourself.
- · Do not use flammable sprays or liquid detergents. · Do not allow children to clean or maintain
- the unit Before cleaning or maintaining, ensure unit is off
- and unplugged.

SAFETY AND CAUTIONS

Before operating this equipment, carefully read and follow these safety cautions and instructions to avoid damage and

Ensure filters are inserted before running unit

Running unit without filters can shorten the units life and cause electric shock or injury.

Be sure foreign objects are NOT inserted into the vents on the unit

Do not touch any part of the interior of the unit with wet hands The high voltage may cause electric shock.

Ensure unit intake and outlet vents do not become blocked

Blockage may lead to increased internal temperatures causing product failure and derformation.

Do not use the unit as a step stool or place heavy objects on it

Personal injury may occur or product failure and deformation.

WARNING

Follow these instructions to reduce the risk of serious injury or death and to reduce risk of damaging the unit.

Do not pull on the power cord when unplugging the unit.

A

Do not tie or knot the power cord when unit is in operation.

A If the unit becomes submerged in water, unplug it and contact customer service.

Do not unplug or move the unit while in operation.

A A

Do not plug additional appliances into the same outlet or power supply.

A Do not touch the plug with wet hands.

Do not place unit closer than 30 cm from the wall during operation. It may cause condensation to the wall and A

A

Unplug the unit when not in operation for extended periods of time.

A Cord can become damaged by forcefully bending, pulling, twisting, bundling, pinching or placing heavy objects on it.

- · If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- This appliance is not intended for use by a person (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- · Children should be supervised to ensure that they do not play with the appliance.

FREQUENTLY ASKED QUESTIONS

Problem	Check / Actions to take Problem		Check / Actions to take	
It does not turn on at all.	Is there a power outage? Check to see if other lights and electrical equipment are working and try again.	The power plug and outlet feel hot	Is the plug securely plugged in? Make sure the plug is properly plugged into the outlet.	
It doesn't work in Auto Mode.	Has Auto Mode been selected? Press the Mode button until Auto Mode is selected. Is the sensor blocked or clogged? Clear the sensor using a vacuum cleaner.	There is a strange smell.	Is it being used in a place with a lot of smoke, dust, or odours? Clean the air intakes on the front sides of the unit and clean the Pre-Filter. Contact customer service to confirm the exact cause. Replace the Deodorization Filter and True HEPA Filter.	
It vibrates and makes a lot of noise.	Is it running on a slanted or uneven surface? Move the unit to a hard, flat, even area of the floor.	The product is not purifying the air enough.	Is the Check Filter indicator light on: Change the filters as required.	

9

SAFETY INSTRUCTIONS

Thank you for purchasing a Winix air purifier. This product is for household use only.

IMPORTANT CAUTIONS FOR USING YOUR AIR PURIFIER

WARNING: Follow the instructions in this manual to reduce the risk of electric shock, short circuit, and/or fire.

- Do not repair or modify the unit unless specifically recommended in this manual. All other repairs should be completed by a qualified technician.
- Do not use if the power cord or plug is damaged or the connection to the wall outlet is loose.
- Use AC 220 240 V only.
- · Do not damage, break, forcefully bend, pull, twist, bundle, coat, pinch, or place heavy objects on the power cord.
- · Periodically remove dust from the power plug. This will reduce the risk of shock due to humidity build
- · If the power plug is damaged, it must be replaced by the manufacturer or a qualified technician.
- Remove the power plug from the outlet before cleaning the unit. When removing the power plug, grasp by holding the plug itself, never hold by the
- Remove the power plug from the outlet when not in

IMPORTANT PRECAUTIONS FOR USING YOUR AIR PURIFIER

- · Do not block the intake or outlet vents.
- · Do not use near hot objects, such as a stove.
- · Do not use where the unit may come into contact with steam.
- . Do not use the unit on its side
- · Keep away from products that generate oily residue, such as a deep fryer.

- · Do not handle the power plug with wet hands.
- · Do not operate the unit when using indoor smokegenerating insecticides.
- Do not clean unit with benzene or paint thinner. Do not spray insecticides on the unit
- · Do not use the unit where it is humid or where the unit may become wet, such as the bathroo
- · Do not insert fingers or foreign objects into air intake or outlet.
- Do not use the unit near flammable gases. Do not use near cigarettes, incense, or other sparkcreating items.
- · Unit will not remove carbon monoxide emitted from heating appliances or other sources.
- This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with the appliance.

- · Do not use detergent to clean the unit.
 - · Do not operate without a filter.
 - · Do not wash and reuse the True HEPA Filter or the Deodorization Filter.
 - · Hold the handle on the back of the unit to transport.
 - · Do not hold by the front panel.

UNIT SPECIFICATIONS

Model Name	AUS-1250AZPU
Power Voltage	220 - 240 V, 50 / 60 Hz
Power Rate	50 W
Recommended room capacity	49.5 m ²
Weight 8.5 kg	
Dimensions 415 mm(W) x 245 mm(D) x 600 mm(H)	
Replacement Filter	FILTER GU, item : 1712-0095-01 FILTER GJ, item : 1712-0092-01

X The exterior, design, and product specifications may be changed without prior notice to improve product

PRODUCT WARRANTY


Product Name		Air Purifier
Model Name		AUS-1250AZPU
Purcha	se Date	
Warrant	ty period	Two (2) Years
Place of	purchase	
Place of pu	ırchase Tel.	
	Address	
Customer	Name	
	Tel.	

* After purchase, be sure to complete all of the above information

WINIX

User Manual

AIR PURIFIER



Model ZERO+ (AUS-1250AZPU)

Use & Care Guide



- Please read and follow all safety rules and instructions in this manual before operating
- The product warranty is printed on the back of this guide, so please keep it in a safe place for future use.



WINIX

AUSCLIMATE FILTER CLUB

For exclusive savings on replacement filters ausclimate.com.au/replacement-filter-club

Contact for product related inquiries and customer service

Distributed by **Ausclimate Pty Ltd** To expedite service, please specify the model name and number, the nature of the problem, your contact information, and your address.

After sales and warranty enquiries, visit website or call 1800 122 100 Website: www.ausclimate.com.au / www.winixaustralia.com.au

2610-0208-01 Rev.02

10