

Assembly of the Water Reservoir and Tiles

Watch the full assembly video for assembling the water reservoir on our website:

www.waterups.com.au/product/waterups-oasis-1680-wicking-bed

- 1: Take the liner and fold the ends as shown in the video.
- 2: Push the three tabs in the corners from the outside in and repeat the entire process for the next three corners, creating the square base liner.
- 3: Place the liner inside the planter, make sure the hole in the liner and the hole in the planter match up.
- 4: Take one of your cells and the overflow pipe and assemble as shown in the video.
- 5: Feed the tile and the overflow pipe through the hole in the reservoir and the planter and ensure it sits flat in the bottom of the reservoir. Replace the spacer on the overflow pipe and tighten the nut.
- 6: Place the next 6 cells into the bottom of the planter.
- 6: Take the last tile and the inlet pipe. With a sharp knife remove the circle in the tile along the line as indicated in the video.
- 7: Insert the inlet pipe into the tile. Take note of the three tabs on the inlet pipe that will fit through the three holes in the tile. Apply some pressure until it clicks in.
- 8: Insert this tile in the end of the planter. Decide if you want the inlet at the side or back.

Filling your Planter

For suggestions about soil for wicking beds and other relevant information visit our website.

Oasis 1680

Self-Watering Wicking Bed Kit

by



Before you start

Watch the full assembly video for your Self-Watering Wicking Bed Kit on the Waterup Website.

www.waterups.com.au/product/waterups-oasis-1680-wicking-bed


Scan the QR Code to go to the website




This information booklet is printed on recycled paper. Please compost or recycle this when you are finished.

www.waterups.com.au | Email: sales@waterups.com.au | Phone: 1300 205 550

What You Will Need



- No. 2 Phillips Head Screw Driver
- Sharp Knife
- Around 3m² of ground to build on



Assembly of the Metal Planter

- 1: Assemble the Bottom Rails by inserting and tightening screws first in the corner brackets and then join both ends with the connector rails. Then flip the entire Bottom Rail assembly over
- 2: Correctly position the corner panels so the short side is at the end. Insert and fasten screws to connect the Corner Panel to the Bottom Rail Assembly
- 3: Insert the Side Panels - there are two sizes, a long and short. On the long panel one of the ridges has an extra kink in it. This kink needs to go to the centre of the side panel. Also insert a panel into the two ends.
- 4: Fit the End Top Rail. Make sure the long edges are on the inside.
- 5: Fit the Side Rails ensuring that the corner bracket fits over the end rail and that the holes line up.
- 6: Place the two connector rails and insert and tighten screws to complete the top rail assembly.
- 7: Insert and tighten screws to secure the entire Top Rail assembly to the rest of the planter.

